

Changing the seat depth on the combi JR (what's different to combi)!

The only thing which is different and needs some explanation is the adjustment of the reclining actuator:



Lift up the chair to a certain standing.



Release the bolt in front of the actuator.



Release the bolt behind the cylinder of the actuator. Lower the actuator in between the space on the lower frame.



Push the backrest forward and move the actuator downwards until the bolts will appear from underneath the cover.



Make now the correct adjustments with these bolts such as with the other depth adjustments and reassembly the actuator the other way around.